

Divergence Indoor Pendant 138930


Page 1 of 6


**CAUTION:** FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

**Please Note:** After installation extra hardware and accessories are possible due to our kits are used on multiple products and options.







### **Component Parts**

A Crossbar

B Threaded Nipple

C Lock Nut

D Cap

E Canopy

F Ground Screw

G Safety Cable

H Assembly H

I Assembly I

J Assembly J

K Canopy Pipes (3)

L Set Screw (9)

M Clutch (3)

N Tri-plate

O Nut

P Lock Washer





Divergence Indoor Pendant 138930

To Install Canopy (Figure 1)


Component Parts

A Crossbar D Cap G Safety Cable

B Threaded Nipple E Canopy
C Lock Nut F Ground Screw

#### Caution: Be sure power is off at the main breaker box prior to installation.

- 1. Carefully unpack the fixture from the carton. Locate crossbar (A), threaded nipple (B) with cap (D), and the lock nut (C).
- 2. Using two machine screws (not provided), fasten the crossbar (A) to the electric box.
  - **Note:** A new electric box comes with screws. When replacing a fixture, retain the existing screws for use with the new fixture.
- 3. Unscrew the cap (D) from the end of the threaded nipple (B). Screw the threaded nipple (B) into the cross bar (A).
- 4. Lift canopy (E) up to the ceiling allowing the threaded nipple (B) to come through the hole in the center of the canopy (E).
- 5. Screw the cap (D) onto the threaded nipple (B) to hold the canopy (E) to the ceiling. Adjust the height of the threaded nipple (B) until the cap (D) tightens fully with the canopy (E) flush to the ceiling.
- 6. Remove cap (D) and canopy (E) from threaded nipple (B).
- 7. Thread lock nut (C) onto threaded nipple (B) until it hits the crossbar (A). This will lock the height of the threaded nipple (B)
- 8. Unscrew and use one of the machine screws from the crossbar (A) to attach the safety cable (G) from the canopy (E) to the crossbar (A). Suspend the canopy (E) from the safety cable (G).
- 9. See following pages to complete installation



(continued)





Divergence Indoor Pendant 138930


### To Assemble Fixture (Figure 2)

#### Component Parts

- E Canopy
- H Assembly H
- I Assembly I
- J Assembly J
- K Canopy Pipes (3)
- L Set Screws (9)
- 1. Locate assembly H, which has the shortest vertical pipe of the 3 assemblies.
- 2. Unscrew the clutch (M) from the canopy pipe (K) and slide the clutch (M) and the plastic sleeve over the wires and onto the vertical pipe of assembly H.
- 3. Slide the canopy pipe (K) over the vertical pipe of assembly H and tighten set screw (L) into clutch (M) enough to hold assembly H during installation and then set assembly H aside.
- 4. Locate assembly I, which has the medium length veritcal pipe out of the 3 assemblies.
- 5. Repeat step 2 and 3 for assembly I.
- 6. Locate assembly J, which has the longest vertical pipe of the 3 assemblies.
- 7. Repeat step 2 and 3 for assembly J.
- 8. Run the wires from assembly H through one hole of the tri-plate (N) and bring that plate down to rest on top of the clutch (M)
- 9. Run the wires from assembly H
  through a hole in the canopy (E) and
  secure assembly H to the canopy
  using a provided lock washer (P) and nut (O). Orient assembly H so that the longer of the two downward pipes is
  pointing toward the center of the canopy (E)
- 10. Repeat steps 7 & 8 for assembly I
- 11. Repeat steps 7 & 8 for assembly J
- 12. One clutch (M) at a time, loosen set screw (L) and adjust the assemblies as far as necessary to give you the total length of the fixture which you desire. There must be a minimum 1-1/2" of vertical pipe inside the canopy pipe (K).
- 13. Tighten the set screw (L) in clutch (M) firmly with hex wrench provided.
- 14. See following pages to complete installation

(continued)





M Clutch (3)

Nut

Tri-plate




Divergence Indoor Pendant 138930

To Install Fixture (Figures 3)

#### Component Parts

- B Threaded Nipple
- D Cap
- E Canopy
- 1. Using one of the provided wire nuts connect four (4) of the black wires from the fixture with one of the provided black lead wires
- 2. Using another one of the provided wire nuts connect four (4) of the white wires from the fixture with one of the provided white lead wires
- 3. Connect the remaining end of the white lead wire and the two remaining white fixture wires to the white supply wire
- 4. Connect the remaining end of the black lead wire and the two remaining black fixture wires to the black supply wire
- 5. Using one of the provided wire nuts connect three (3) of the copper ground wires from the fixture with one of the provided copper ground wires.
- 6. Using one of the provided wire nuts connect the remaining three (3) copper ground wires from the fixture with one of the provided copper ground wires.
- 7. Attach a pigtail lead to the crossbar ground screw. Connect all ground wires (bare copper or green to bare copper or green). *Caution: Make sure wire connectors are twisted on securely, and no bare wire is exposed.*
- 8. Slide canopy (E) over threaded nipple (B) and push firmly to ceiling, making sure no wires are pinched between fixture canopy and ceiling. Fasten with cap (D) making sure that the nipple is fully seated inside the cap (D). (Figure 3)
- 9. Refer to instructions following to install accents.



(continued)





Divergence Indoor Pendant 138930

To Install Accents (Figure 4 & 5)

#### Component Parts


Assembly H Q Accent Q Accent Holder

Assembly I Accent R Assembly J Accent S

Locate and identify the three accent pieces (Figure 4)

### Note: Each accent has a short arm and a long arm which will determine orientation

- 2. The long arm of accent Q will be installed into the accent holder (T) on the long arm of assembly H and the short arm of accent Q will be installed into the accent holder (T) on the short arm of assembly H (Figure 5)
- Repeat step 2 for accent R and assembly I



If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture

Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.



(Figure 5)